Thank you for choosing the 70mai Smart Dash Cam Pro

The 70mai Smart Dash Cam Pro is equipped with professional video recording chip and image sensor for capturing high-quality videos.


How to use

Please visit the website below for instructions. Before using this product, please read the instructions carefully to avoid loss due to improper usage.

https://help.70mai.asia/278.html

The specific functions and contents of this product may be adjusted due to various business reasons. We cannot guarantee the timely update of related packaging and instructions. Please refer to the functions and contents of the product during actual use.

Product overview







Please install the product following the method 1. Install the electrostatic sticker

Take out the electrostatic sticker from the packing box and

Installation

install it in the recommended area on the windshield, as shown in the figure below.

Please clean the windshield, and remove the air bubbles between the electrostatic sticker and the windshield during the installation.



2. Connect the Dash Cam Pro to the bracket

Lock the bracket to the Dash Cam Pro, as shown in the figure below. You will hear a snap when it is in place.



3. Attach the Dash Cam Pro

Remove the protective sticker on the Dash Cam Pro bracket and attach the Dash Cam Pro to the center of the electrostatic sticker, as shown in the figure below.

Press the bracket mount by hand to ensure that the heat resistant adhesive is in close contact with the electrostatic



4. Connect the power supply

As shown in the figure, run the power cable along the top of the windshield, down pillar A, and around the passenger-side glove compartment. Arrange the end so that it runs to the cigarette lighter port. After connecting it to the car charger, plug the charger into the port.



5. Adjust the Dash Cam Pro angle

Turn on the Dash Cam Pro and adjust the camera angle up and down against the preview screen to ensure that the camera is facing the front

Activating 70mai Smart Dash Cam Pro

The 70mai Smart Dash Cam Pro must be activated using the 70mai app. Please visit the website below to download and install the 70mai

https://www.70mai.com/en/download/

Please select "Add Device" in the 70mai app and complete the activation according to the prompts.

Box contents

- 1. 70mai Smart Dash Cam Pro × 1
- 2. Car charger × 1
- 3. USB cable × 1
- 4. Flectrostatic sticker × 2
- 5. Wiring tool × 1
- 6. Heat resistant adhesive × 1
- 7. Mounting bracket × 1
- 8. Manual × 1

Service: help@70mai.com For further information, please go to www.70mai.com

Accessory

This device can be used together with 70mai GPS Mount Holder(sold separately).

After being properly installed and connected with the mount holder, you can enable ADAS and other functions on the device.

Please visit the website below for instructions of the GPS mount holder.

https://help.70mai.asia/347.html

Important notices

Please read all precautions and instructions carefully before using this product to ensure proper and safe usage.

- This product is a vehicle accessory that records external video footage. The usage of this product does not guarantee the safe driving of users. We are not responsible for driving accidents and other losses that result from product failure, loss of data, or the operation of this product.
- · Certain functions of this product may not work properly due to differences in vehicle conditions, driving style, and driving environment. Power disconnection, usage outside of normal temperature and humidity, impact, and memory card damage may cause this product to malfunction. We do not guarantee normal operation under all circumstances
- Please install this product properly and do not block the driver's line of sight or the vehicle airbag to avoid product failure and personal injury.
- Please use the car charger and USB cable that comes with this device to avoid compatibility issues. 70mai is not responsible for any loss caused by the use of non-standard car chargers and USB cables.

- . The memory card is not included in the package. You will need to buy it by yourself.
- . The default file format of the memory card may not be compatible with the format supported by this product. When inserting a memory card for the first time, format it in the dash cam before use.
- · Please use a good quality memory card purchased through official channels. Poor quality memory cards may have problems such as the nominal read/write speed does not match the actual read/write speed, and the nominal capacity does not match the actual capacity. 70mai is not responsible for lost or damaged video footage caused by the use of a poor quality memory card.
- . If the battery is deformed, swelling, or leaking, stop using the product immediately and contact customer service. . Keep this product away from strong magnetic fields, which
- may cause damage to the product. Do not use this product at temperatures above 60℃ or
- Please use this product to the extent permitted by law.

below -10°C.

Keep the product at least 20cm away from the driver and

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Specifications Model: Midrive D02

Image sensor: SONY IMX335 Resolution: 2592 × 1944 Camera: FOV 140°, F1.8, 6 glass Wireless connection: Wi-Fi IEEE 802.11 b/a/n/ 2.4GHz G-sensor: Acceleration sensor Expandable memory: MicroSD card with capacity of 16-64GB and read/write speed of Class10 and above Supported OS: Android4.4/iOS8.0 and above Power supply: car cigarette lighter Battery type: li-polymer battery Battery capacity: 500mAh Input: 5V == 2A Operating temperature: -10°C ~ 60°C Dimensions: 82 × 58.2 × 40.5mm

70mai Smart Dash Cam Pro

Please read this manual carefully before using the product and keep it in a safe place.



